

Lesson 1 - Attaching the elasticated webbing to your wooden frame

Tools and materials needed; wooden frame, staple gun, elasticated webbing and scissors.

Put the furniture frame with the wooden corner brackets facing down to your work area. The corner brackets are there to attach your furniture legs at the end

You are going to attach the elasticated webbing to your furniture frame. Staple webbing on first side leaving approx 1 inch / 2 finger spaces between each web.

Once finished repeat same process on the other side but now weave the webbing over and under & staple into place. Watch Lesson 1 video for detailed instructions.

