

Lesson 4 - Attach dacron to frame

Tools and materials needed; wooden frame, a piece of dacron big enough to cover the frame, old dust sheet to protect workspace, spray adhesive.

Measure and cut a piece of dacron big enough to cover the foam and frame.

Top tip; shake spray adhesive can well and clear nozzle before use to make sure it sprays out clearly.

You will be attaching the dacron on top of foam/frame. You will be using a bit of spray adhesive to secure in to place. Watch Lesson 4 video for detailed instructions.

