## Lesson 5 - Get the measurements for your top fabric.



Tools and materials needed; completed wooden frame, soft tape measure, pen and paper

Top tip; have pen and paper to hand to write down your measurements.

To calculate the width of your fabric you will need to include wrap the tape measure round the frame including;

Width of frame + sides of frame/foam (x2) +5cm extra for allowance (x2)

To calculate the height of your fabric you will need to include wrap the tape measure round the frame including;

Height of frame + sides of frame/foam (x2) +5cm extra for allowance (x2)

Watch Lesson 5 video for detailed instructions.

